


Quick Reference Guide





Green Thinking

About This Guide

The Q-Wash 560Z-LED Quick Reference Guide (QRG) contains the product's connection and mounting information, as well as the menu options and the DMX values.

Disclaimer

- Refer to this product's User Manual for detailed information and instructions. You can download the User Manual from the CHAUVET® website: www.chauvetpro.com.
- Read ALL the disclaimers and Safety Notes in this document, as well as those in the product's User Manual before installing, operating, or maintaining this product.

Safety Notes

- DO NOT open this product unless instructed. It contains no user serviceable parts.
- DO NOT look at the light source when this product is on.
- DO NOT touch the product when it is operating because it may be hot.
- DO NOT cover the ventilation slots when the product is operating to avoid internal overheating.
- DO NOT install or operate this product where there is less than 50 cm to the nearest surface to allow adequate ventilation around it.
- DO NOT leave any flammable material within 50 cm from this product while operating or connected to the power outlet to minimize the risk of fire.
- DO NOT carry this product from the head. Use the handles instead.
- DO NOT mount this product overhead without using a safety cable.
- DO NOT operate this product outdoors or in any location where dust, excessive heat, water, or humidity may affect it.
- DO NOT operate this product if you see damage on the housing, lenses, or cables. In any of these cases, have the damaged parts replaced by an authorized technician at once.
- DO NOT connect this product to a dimmer or rheostat.
- ONLY connect this product to a grounded and protected circuit.

What Is Included

- One Q-Wash 560Z-LED
- One IEC Power Cord with Edison Plug (US market)
- One Safety Cable
- Two Omega Brackets
- Warranty Card
- Quick Reference Guide

Features

- 12 or 15-channel RGBWA LED moving yoke wash product
- Pan: 540°
- Tilt: 270°
- RGBWA color static mixing with or without DMX control
- Vector speed channel for RGBWA color mixing
- Variable zoom
- Variable electronic strobe
- Continuously variable electronic dimmer (0~100%)
- Built-in automated programs
- Remote product reset and vector speed channel
- 255-step fully customizable program
- Recall auto or custom programs via control panel or DMX
- Color temperature presets (3,200~10,000 K)

AC Power


This product has an auto-ranging power supply that works with an input voltage range of 100~240 VAC, 50/60 Hz.

Fuse Replacement

- 1. Disconnect the unit from the power outlet.
- With a flat head screwdriver, wedge the fuse holder out of the housing and remove the blown fuse from the holder.
- 3. Replace the blown fuse with a fuse of the exact same type and rating.
- 4. Insert the fuse holder back in place and reconnect the power.

Mounting

Before mounting this product, read the Safety Notes at the beginning of this guide and on page 2 of the product's User Manual. Then, follow the mounting procedure indicated in the *Setup* chapter of the User Manual.



Menu Options

1 st Level	2 nd Level	3 rd Level	Description	
	ADDRESS	001~512	Selects a starting DMX address	
	RESET	NO/YES	Resets the product's custom settings	
		HIGH	Select the fan's operation mode.	
	FAN	NORMAL	NOTE: Product's controller will force the fan to High if the	
	FAN	LOW	product's internal temperature becomes too high, despite any	
		AUTO	manual or DMX setting	
		DMX512	Selects DMX running mode	
		AUTO 1	Selects the first automatic program	
	RUN	AUTO 2	Selects the second automatic program	
INTRO		CUSTOM	Selects the user customizable program	
iitiito		SLAVE	Selects the Slave running mode	
		TEST	Starts the product's test sequence	
	CHANNELS	BASIC	Selects the 11-channel DMX mode	
	OHAMILLO	ADVANCED	Selects the 15-channel DMX mode	
	DISPLAY	60 CLOSE	Turns off the display after 60 seconds	
		BRIGHT	Keeps the display on	
	KEYLOCK	NO/YES	Activates/deactivates the control panel password	
	DIMMER	DIMMER 4~1	Slow (DIM 4) to fast (DIM1) dimmer curves	
		DIMMER 0	Linear dimmer	
	INFO	EDITION	Shows the version of the installed S/W	
	Pan	NORMAL/	Defines the pan direction	
INVERT	Tilt	REVERSE	Defines the tilt direction	
	Dimmer	NONES	Defines the direction of the dimmer fader	
	Use	NO/YES	Activates the changes	
	P/Start		Sets the pan start point (restricted range)	
DANCE	P/Finish T/Start	200 055	Sets the pan end point (restricted range)	
RANGE	T/Finish	000~255	Sets the tilt start point (restricted range)	
	Use		Sets the tilt end point (restricted range) Activates the changes	
-	Black delay	NO/YES	Activates the move-in black delay (3 s)	
	Black delay	DMX	The DMX controller can reset the product	
	Reset	SYSTEM	The control panel can reset the product	
			LEDs illuminate at normal or high intensity	
	Power	NORMAL/ HIGH	NOTE: Product will return to Normal if temperature becomes too	
SPECIAL	1 01101		high	
00		UC	White output matches that of older products	
	Color	RGBTOW	White output set by RGB-W	
		OFF	White output defined by RGBW faders	
	Fan	DMX	The DMX controller can set the fan speed	
		SYSTEM	The control panel can reset the fan speed	
	STEP		Selects the program step	
EDIT	PAN	1	Selects the pan position	
	TILT		Selects the tilt position	
	SPEED	1	Selects the pan/tilt speed	
	RED	000~255	beleets the pain the speed	
EDII		000~200	Combines red, green, blue, white, and amber to obtain a custom color	
	GREEN			
	BLUE]		
	WHITE			
	AMBER			

Continues in the next page

Continued from previous page

1st Level	2nd Level	3rd Level	Description	
	DIMMER	000~255	Selects the dimmer value	
EDIT (Cont.)	STROBE		Selects the strobe frequency and mode	
	ZOOM		Select the zoom position	
	DIMSPEED		Selects the dimmer speed	
	TIME		Selects the step duration	
	USE	No/Yes	Activates the changes	
EXTRA	PASSWORD	****	Opens the Extra menu (see below)	

Extra Menu

1 st Level	2nd Level	3rd Level	4 th Level	Description
		Red		
	3200 K	Green	000~255	Sets color temperature for Macro > White 1
		Blue		•
	3400 K	Red	000~255	Sets color temperature for Macro > White 2
		Green		
		Blue		
	4200 K	Red	000~255	Sets color temperature for Macro > White 3
		Green		
		Blue		
		Red		Sets color temperature for Macro > White 4
	4900 K	Green	000~255	
		Blue		
		Red		
	5600 K	Green	000~255	Sets color temperature for Macro > White 5
		Blue		
		Red		
	5900 K	Green	000~255	Sets color temperature for Macro > White 6
Calib		Blue		
Calib	6500 K	Red	000~255	Sets color temperature for Macro > White 7
		Green		
		Blue		
	7200 K	Red	000~255	Sets color temperature for Macro > White 8
		Green		
		Blue		
	8000 K	Red	000~255	Sets color temperature for Macro > White 9
		Green		
		Blue		
	8500 K	Red	000~255	Sets color temperature for Macro > White 10
		Green		
		Blue		
	10000 K	Red	000~255	Sets color temperature for Macro > White 11
		Green		
		Blue		
	RGB-W	Red	000~255	Sets color temperature for Special > Color > RGBtoW
		Green		
		Blue		
Default	Default	No/Yes	N/A	Defaults the product to factory settings

DMX Values

BASIC

Channel	Function	Value	Percent/Setting
1	Pan	000 ⇔ 255	0~540°
2	Tilt	000 ⇔ 255	0~270°
3	Red	000 ⇔ 255	0~100%
4	Green	000 ⇔ 255	0~100%
5	Blue	000 ⇔ 255	0~100%
6	White	000 ⇔ 255	0~100%
7	Amber	000 ⇔ 255	0~100%
8	Power and Color Macro	000 ⇔ 005 006 ⇔ 010 011 ⇔ 030 031 ⇔ 050 051 ⇔ 070 071 ⇔ 090 091 ⇔ 110 111 ⇔ 130 131 ⇔ 150 151 ⇔ 170 171 ⇔ 200 201 ⇔ 205 206 ⇔ 210 211 ⇔ 215 216 ⇔ 220 221 ⇔ 225 226 ⇔ 230 231 ⇔ 235 236 ⇔ 240 241 ⇔ 245 246 ⇔ 250	No function High power R: 100% G: Up B: 0% R: Down G: 100% B: 0% R: 0% G: 100% B: Up R: 0% G: Down B: 100% R: Up G: 0% B: 100% R: 100% G: Up B: Up R: Down G: Down B: 100% R: 100% G: Up B: Up R: Down G: 100% B: 100% White 1: 3200 K White 2: 3400 K White 3: 4200 K White 4: 4900 K White 5: 5600 K White 7: 6500 K White 8: 7200 K White 9: 8000 K White 9: 8000 K White 9: 8000 K
9	Dimmer	251 ⇔ 255 000 ⇔ 255	White 11: 10,000 K 0~100%
		000 ⇔ 009	No function
10	Strobe	010 🖨 255	01~20 Hz
11	Zoom	000 ⇔ 255	6~37°
12	Control	000 ⇔ 019 020 ⇔ 039 040 ⇔ 059 060 ⇔ 079 080 ⇔ 099 100 ⇔ 119 120 ⇔ 139 140 ⇔ 149 150 ⇔ 169 170 ⇔ 179 180 ⇔ 199 200 ⇔ 219 220 ⇔ 235 236 ⇔ 239 240 ⇔ 243 244 ⇔ 247 248 ⇔ 251 252 ⇔ 255	No function Pan/tilt black activation Pan/tilt black deactivation Automatic fan speed Slow fan speed Normal fan speed High fan speed Auto program 1 (3 s activation delay) Auto program 2 (3 s activation delay) Test (3 s activation delay) Custom program (3 s activation delay) No function Reset (3 s activation delay) No function DIMO (3 s activation delay) DIM1 (3 s activation delay) DIM2 (3 s activation delay) DIM3 (3 s activation delay) DIM3 (3 s activation delay) DIM4 (3 s activation delay)

ADVANCED

Channel	Function	Value	Percent/Setting
1	Pan	000 ⇔ 255	0~540°
2	Pan Fine	000 <code-block></code-block>	Fine movement control
3	Tilt	000 ⇔ 255	0~270°
4	Tilt Fine	000 🗢 255	Fine movement control
5	Pan/Tilt Speed	000 ⇔ 255	Fast~Slow
6	Red	000 ⇔ 255	0~100%
7	Green	000 ⇔ 255	0~100%
	Blue	000 ⇔ 255	0~100%
9	White	000 ⇔ 255	0~100%
10	Amber	000 🖨 255	0~100%
11	Power and Color Macro	000 ⇔ 005 006 ⇔ 010 011 ⇔ 030 031 ⇔ 050 051 ⇔ 070 071 ⇔ 090 091 ⇔ 110 111 ⇔ 130 131 ⇔ 150 151 ⇔ 170 171 ⇔ 200 201 ⇔ 205 206 ⇔ 210 211 ⇔ 215 216 ⇔ 220 221 ⇔ 225 226 ⇔ 230 231 ⇔ 235 236 ⇔ 240 241 ⇔ 245 246 ⇔ 250	No function High power R: 100% G: Up B: 0% R: Down G: 100% B: 0% R: 0% G: 100% B: Up R: 0% G: Down B: 100% R: Up G: 0% B: 100% R: 100% G: Up B: Up R: 000 G: Up B: Up R: 000 G: Up B: Up R: 100% G: Up B: Up R: 100% G: 100% B: 100% White 1: 3200 K White 2: 3400 K White 3: 4200 K White 4: 4900 K White 5: 5600 K White 7: 6500 K White 9: 8000 K White 9: 8000 K White 9: 8000 K
		251 ⇔ 255	White 10: 8500 K White 11: 10,000 K
12	Dimmer	000 ⇔ 255	0~100%
13	Strobe	000 ⇔ 009 010 ⇔ 255	No function 01~20 Hz
14	Zoom	000 ⇔ 255	6~37°
15	Control	000 \(\phi\) 019 020 \(\phi\) 039 040 \(\phi\) 059 060 \(\phi\) 079 080 \(\phi\) 099 100 \(\phi\) 119 120 \(\phi\) 139 140 \(\phi\) 159 160 \(\phi\) 179 170 \(\phi\) 179 200 \(\phi\) 219 220 \(\phi\) 235 236 \(\phi\) 239 240 \(\phi\) 243 244 \(\phi\) 247 248 \(\phi\) 255	No function Pan/tilt black activation Pan/tilt black deactivation Automatic fan speed Slow fan speed Normal fan speed High fan speed Auto program 1 (3 s activation delay) Auto program 2 (3 s activation delay) Test (3 s activation delay) Custom program (3 s activation delay) No function Reset (3 s activation delay) No function DIMO (3 s activation delay) DIM1 (3 s activation delay) DIM2 (3 s activation delay) DIM3 (3 s activation delay) DIM3 (3 s activation delay) DIM4 (3 s activation delay)

Control Panel Description

Button	Function	
<menu></menu>	Exits from the current menu or function	
<enter></enter>	Enables the currently displayed menu or sets the currently selected value into the selected function	
<up></up>	Navigates upwards through the menu list and increases the numeric value when in a function	
Navigates downwards through the menu list and decreases the numeric value when in a function		

Programming

For details on how to program this product, please refer to the product's User Manual.

Password

After being prompted to enter the password, press:

<UP>, <DOWN>, <UP>, <DOWN>, and <ENTER>

Contact Us

World Headquarters
CHAUVET®

General Information

Address: 5200 NW 108th Avenue Surrise, FL 33351
Voice: (954) 929-1115
Fax: (954) 929-5560
Toll free: (800) 762-1084

Technical Support

Voice: (954) 929-1115 (Press 4) Fax: (954) 756-8015 Email: tech@chauvetlighing.com

World Wide Web

www.chauvetpro.com

United Kingdom and Ireland CHAUVET® Europe Ltd.

General Information

Address: Unit 1C Brookhill Road Industrial Estate Pinxton, Nottingham, UK

NG16 6NT Voice: +44 (0)1773 511115 Fax: +44 (0)1773 511110

Technical Support

Email: uktech@chauvetlighting.com

World Wide Web

www.chauvetlighting.co.uk

Outside the US, United Kingdom, or Ireland, contact your distributor of record. Follow their instructions to request support or to return a product. Visit our Web site for contact details.

Q-Wash 560Z-LED QRG – Rev. 06
© Copyright 2011 CHAUVET®
All rights reserved.
Printed in the P. R. C.

